

SHOCK ABSORBERS

DETAIL OF PRODUCT RANGE

MERCEDES BENZ

MERCEDES BENZ – TRUCK (CABIN)	
OEM REF.	OUR REF.
000 891 2205	382205
000 891 0305	380305
000 891 2005	382005
942 890 2819	992819
942 890 3119	993119
942 890 3619	993619
942 890 4719	384719
942 890 5419	995419
942 890 1619	991619

MERCEDES – BUS (FRONT)	
OEM REF.	OUR REF.
302 326 0500	630500
003 326 7500	637500
671 323 0300	630300
356 323 0500	800500
357 326 0100	500100
357 326 0000	630000
357 323 0400	730400
357 323 0600	630600

MERCEDES – BUS (REAR)	
OEM REF.	OUR REF.
357 326 0100	500100
357 326 0000	630000
671 326 0100	630100
356 326 0700	630700
357 326 0300	630300

**MERCEDES BENZ – TRUCK
(REAR)**

OEM REF.	OUR REF.
004 326 1300	500731
970 326 0700	551300
674 326 1400	550700
003 326 9900	551400
004 326 1800	739900
003 326 9600	731800
675 326 0600	739600
005 326 4600	730600
002 326 5200	735200
003 326 1500	731500
003 326 9200	739200
004 326 7100	737100
314 326 0600	550600
387 326 0300	730300
003 326 8500	738500
391 326 0100	730100
387 326 0100	730100
004 326 4700	734700
005 323 1800	731800
003 326 1500	731500
005 326 3100	733100
387 326 0200	730200
003 326 7900	737900
623 326 0000	730000
003 326 5100	735100
005 326 6300	736300
005 326 1400	731400
005 326 1100	731100
005 326 1200	731200

MERCEDES BENZ – TRUCK (FRONT)		MERCEDES BENZ – TRUCK (FRONT)	
OEM REF.	OUR REF.	OEM REF.	OUR REF.
601 320 0730	500730	004 323 3300	553300
601 320 0430	500430	004 323 5500	555500
314 326 0600	500600	675 323 1000	501000
675 323 0400	500400	006 323 0900	550900
005 323 0900	500900	004 323 4400	554400
004 323 7500	507500	004 326 0300	550300
004 323 7400	557400	003 326 4400	554400
004 323 4500	554500	004 323 4300	554300